

# BATTEN UV INSTALLATION INSTRUCTIONS

## BATTEN UV BASIC INSTALLATION



Apply vertical chalk lines every 16 inches on-center at the stud locations for Batten UV layout.

Install Batten UV vertically or horizontally, at 16 inches on-center, or diagonally, at 12 inches on-center, over the Benjamin Obdyke housewrap - making sure that the fasteners are aligned with stud locations.

Install 1.25 inch roofing nails, or other exterior fasteners using the slotted holes. Minimal fasteners are needed to hold the batten in place until the siding is installed. Do not overdrive fasteners to allow expansion prior to cladding installation.

Allow a 3/8 inch space at the end of each batten to allow for expansion.

Battens must be installed behind corner trim and vertical window trim, and can be installed around the perimeter.

Install siding through Batten UV and secured to the structure's framing. Make sure to install siding per manufacturer's instructions.