

AERONET™

compression resistant ventilation mat

BASIC INSTALLATION

Unroll AeroNet™ with the “feet” against the WRB or underlayment.

Ensure the flat side of AeroNet™ is positioned against the back side of the roofing or siding material.

Fasten AeroNet™ with 1 inch cap nails (or 7/8 inch staple) about every 2 feet along the perimeter & about every 9 sq. ft. in the field.

Butt edges of new rolls or new courses together. Do not overlap layers.

IMPORTANT CONSIDERATIONS

AeroNet™ is approved for a roof or wall application to provide an air space under the cladding or roofing material.

This product should not be used with asphalt shingles.

Do not walk on the product and do not overlap the consecutive courses.

Cover with cladding or roofing within 120 days.

800.523.5261
techsupport@obdyke.com

BENJAMIN OBDYKE
roof & wall products